



LAVA ST Plus Quick Install

LAVA recommends installing an HQ Plus before setting up an ST Plus. To set up an ST Plus for polling you will need:


- LAVA ST Plus Configuration Console software
 - LAVA ST Plus with power supply (do not confuse power supply with that of HQ Plus)
 - Windows-based PC with 1 available COM port (1 x DB-9) [not supplied]
 - one Ethernet cable (CAT-5 UTP with RJ-45 connectors) [not supplied]
 - one straight-through serial cable (DB-25M to DB-9F) [not supplied]
1. Install the ST Plus Configuration Console software on the computer and open the application.
 2. Connect a straight-through serial cable to the serial port of the ST Plus and to the computer with the ST Plus Configuration Console software. Choose the COM port to which the ST Plus is attached and click "Connect".
 3. Cycle power on the ST Plus. On ST Plus boot-up, the data fields of the ST Plus Configuration Console will be populated with the settings of the ST Plus.
 4. In the screen that appears, DHCP should be checked on (unless you are manually configuring network settings).




5. The fields "Home IP/Port" and "Device Tel No." must be completed.



6. The Identification Key must match that of the HQ Plus to which you are connecting.



7. Set the correct serial port settings. They should match the settings of the polling software, the ECR's communications port, and the HQ Plus modem port.



8. Connect the Ethernet port of the ST Plus to the store's LAN. Click "Write" and then click "Run". You should see a time stamp and a "Connected to Unit: [device name]" message in the Message dialog window.
9. Click "Activate".
10. POLL AWAY!