



LAVA COMPUTER MFG. INC.

2 VULCAN STREET, TORONTO, ONTARIO M9W 1L2
TEL: (416) 674-5942 FAX: (416) 674-8262
www.lavalink.com

TECHNICAL SUPPORT FAQ

TOPIC:	Linux Installation	PRODUCT(s):	LavaPort-ISA
		REVISION:	A00

Installation

On install during the bootup process, Linux detects the LavaPort-ISA and sets the configuration for ttyS2. To verify proper installation you must remember the I/O range (see table below) and IRQ each serial port was jumpered to.

```
ttyS0 = 0x03f8; irq = 4  
ttyS1 = 0x02f8; irq = 3  
ttyS2 = 0x03e8; irq = 4  
ttyS3 = 0x02e8; irq = 3
```

First you must verify that the card was installed correctly. To do this at the command line type:

```
setserial -a /dev/ttyS2
```

Note: ttyS2 refers to Com3. This setting may change depending on how the jumpers are configured on the card.

If the card is correctly configured in Linux you will see the following information:

```
/dev/tty2, Line 2, UART 16650V2, Port: 0x03e8, IRQ: 4  
Baud_base: 460800, close_delay: 256, divisor: 0  
closing_wait: 15360  
Flags: spd_normal skip_test
```

Your port and IRQ should conform to the jumper settings on the card.

If you find that the information displayed does not match the above (port and IRQ should match your jumper settings), then carry on to the next step below. If the data is correct then the installation is complete.

To set the serial port to the correct settings, edit the file:

```
/etc/rc.d/rc.local
```

Add the following line at the end of the file:

```
setserial /dev/ttyS2 port 0x03e8 irq 4 uart 16650v2 baud_base 460800 ^fourport
```

Your port/IRQ may be different depending on the jumper settings on the card. Be sure to save the added changes. On reboot all of the ports should be operational.

[Test OS: Redhat 7.3 and 8.0]